



REMEMBER:

Before installing or adjusting your sights, unload and/or check to ensure the firearm is unloaded.

Bore Guide for DPMS GII & AR

- 1) Verify the rifle is unloaded and all ammunition is removed from the area.
- 2) Push the take down pins from the receiver to allow access to the bolt carrier group.
Helpful tip: Installing the upper on the XS Armorer's Block mounted in a vise makes holding it for maintenance easier!
- 3) Remove the bolt carrier group and charging handle.
- 4) Insert the XS Bore guide with a twisting motion. The small diameter stub goes into the chamber.
- 5) Align the solvent port with the ejection port of the rifle, allowing for easy application of solvents and oils to the patch or brush.
- 6) Once cleaning is complete, wipe the XS Bore Guide with a soft, clean rag prior to storage.