



**REMEMBER:**

Before installing or adjusting your sights, unload and/or check to ensure the firearm is unloaded.

**Benelli Shotgun Front Sight**

1. Loosen and remove the sight mounting nut from the factory front sight.
2. Remove the front sight.
3. Install the XS front sight and tighten mounting nut.
4. To make gross windage adjustments, loosen the mounting nut, move the sight right or left, then retighten the mounting nut.
5. Wipe sights down with protective oil in a light coating to prevent potential rust issues.