



REMEMBER:

Before installing or adjusting your sights, unload and/or check to ensure the firearm is unloaded.

HK UMP/USC, G36/SL8 – Front Sight Installation

1. Place the gun in a padded vise.
2. Drive out the front sight roll pin.
3. Remove the factory front sight.
4. Install the XS front sight.
5. Reinstall the roll pin.